

ELECTRIC TOOL PARTS LIST

■ **PLANER**
Model P 20SA

2001-6-1
(E4-1)



