


KEY SWITCH 725-1296	
OFF	G+M+A
RUN	B+L+A
START	B+S+L

(A)	Green	5 GRD
	Orange	2 BRK+
	Org/Blk	4 Deck+
	Org/Wht	3 Deck-
	Org/Blk	1 Brk-
	Red	8+12V



13AP414A643 HA 4145
 13AP414F643 HF 4145
 13AP416A680 LRH 145 H
 13AP416A690 SPRINT SLX 76 RH
 13AP494A643 HA 4145
 13AP496A690 SLX 76 RH

SCHEM : ELEC : 400 HYDRO : INTEK
 815-04375 WITHOUT PTO

E3-01403 A