

HITACHI

LIST NO. 0661

ELECTRIC TOOL PARTS LIST

■ **PLANER**
Model P 20SD

2001-6-1
(E1-1)



