F 015 556 5A1

Stand ~~99-03~~
Issue 99-06-08

Fig./Abb. 1

WIRING DIAGRAM

WARNING! Electrical repairs should be attempted only by trained repairmen. Contact the nearest SKIL Service Center or other competent repair service.



Änderungen vorbehalten
Modifications reserved
Modifications reservees
Salvo modificaciones